

## LIMITED WARRANTY

ICT Ltd. warrants to the original consumer purchaser that this product shall be in good working order, free from defects in materials and workmanship, for a period of one (1) year from the date of purchase. Should failure occur during the above stated time period, then ICT will, at its option, repair or replace this product at no additional charge except as set forth below. All parts, whether for repair or replacement, will be furnished on an exchange basis. All exchange pieces become the property of ICT. This limited warranty shall not apply if the ICT product has been damaged by unreasonable use, accident, negligence, disaster, service, or modification by anyone other than the ICT factory.

Limited warranty service is obtained by delivering the product during the above stated one (1) year warranty period to an authorized ICT dealer or ICT factory and providing proof of purchase date. If this product is delivered by mail, you will insure the product or assume risk of loss or damage in transit, and prepay shipping charges to the factory.

Every reasonable effort has been made to ensure that ICT product manuals and promotional materials accurately describe ICT product specifications and capabilities at the time of publication. However, because of ongoing improvements and updating of ICT products, ICT cannot guarantee the accuracy of printed materials after the date of publication and disclaims liability for changes, errors or omissions.

If this ICT product is not in good working order, as outlined in the above warranty, your sole remedy shall be repair or replacement as provided above. In no event will ICT be liable for any damages resulting from the use of or the inability to use the ICT product, even if an ICT employee or an authorized ICT dealer has been advised of the possibility of such damages, or for any claim by any other party.

ICT reserves the right to make changes without further notice to any products or documentation for improvement of reliability, function, or design.

ICT Ltd. does not recommend use of its products in life support applications wherein a failure or malfunction of the product may directly or indirectly threaten life or cause injury. The user of ICT products, which are to be used in life support applications as described above, assumes all risks of such use and indemnifies ICT against all damages.

**INNOVATIVE CIRCUIT TECHNOLOGY LTD.**  
26921 GLOUCESTER WAY LANGLEY, BRITISH COLUMBIA, CANADA V4W 3Y3  
T 604.856.6303 F 604.856.6365 [www.ict-power.com](http://www.ict-power.com)



## ICT BASE STATION SERIES INSTRUCTION MANUAL



**INNOVATIVE CIRCUIT TECHNOLOGY LTD.**

855-022-002

## ICT BASE STATION SERIES

The ICT Base Station Series provides a sleek, mobile radio base station. These covers are individually customized to fit various radio models. The ICT Base Station Series covers and ICT Comm Series power supplies may be purchased separately or as a Complete Base Station (power supply assembled with cover).

These instructions should be read before using the product and it should be saved for future reference.


## SETUP

- ▶ Remove power cord from unit before removing cover.  
**CAUTION! HIGH VOLTAGE INSIDE!**
- ▶ Remove 4 screws and washers.
- ▶ Remove backing from foam tape (included) and apply it along the top of the power supply, flush with the front, as shown in diagram "A".
- ▶ Install base station cover over power supply. Re-install 4 screws and washers, adding the 2 supplied star washers in the 2 rear cover holes only. These washers should be between the 2 cover metals as shown in diagram "B". This is required to maintain chassis ground on external metal components.
- ▶ Do not tighten cover screws until radio has been installed and adjusted.

## NOTES

- ▶ ICT Base Station series use thread cutting screws. When reinserting, avoid tapping a second thread in hole.
- ▶ Cover VTX5 for Vertex radios also has a rubber grommet at both radio mounting points. Do not over tighten.

## DIAGRAM "A"



## DIAGRAM "B"

